

3-dimensional microstructure characterization of porous ceramic matrix composites by X-ray tomography and FIB-slicing as database for numerical modelling




M. Bartsch, K. Artzt, M. Eggeler, P. Watermeyer

German Aerospace Center, Cologne



A. Manero

Mechanical and Aerospace Engineering, University of Central Florida,
Orlando, Florida



P. Kenesei

Advanced Photon Source, Argonne National Laboratory,
Argonne, Illinois



Knowledge for Tomorrow



Research Goals

- Visualization of 3d meso- and microstructure of fiber reinforced porous all-oxide CMC's
- Visualization of cracks and other defects, generated during processing, testing or in service - without producing artefacts
- Generating numerical models from 3d-Images of real microstructures




CMC- Material – WHIPOX™

Wound **H**ighly **P**orous **O**xide



Combustion chamber
for small gas turbine




Processing by winding of alumina
fiber bundles infiltrated with
aqueous slurry of alumina powder
and subsequent sintering




Characteristic length scales of WHIPOX™




Diamond pattern of wound fiber bundles (mm – range)




Cross section of adjacent fiber bundles with different orientation




Fibers embedded in porous matrix



Single fiber embedded in porous matrix





Microstructure of porous matrix



TEM-image of porous matrix (courtesy of M. Müller, GFE an der RWTH Aachen)




Non destructive generation of 3d-images by X-ray tomography



➔ Computing 3d-reconstruction from set of X-ray projections of rotated sample (stepwise from 0° to 360°)




Experimental set-up at Argonne Advanced Photon source



- Argonne National Laboratory, Argonne, Illinois
- Synchrotron high energy X-Ray beam-line;
65keV beam energy

Tomography Stage for Data Acquisition




Beam width: 1.8mm




Sample preparation and mounting



Ultrasonic drilling




Sample with $\pm 45^\circ$ fiber bundle orientation






Mounted sample on high temperature and room temperature fixture



Monitoring sets of X-ray projections



Laminate with $\pm 45^\circ$ fiber bundles




Sample

Mounted Sample




X-ray projection



Monitoring sets of X-ray projections



Laminate with $\pm 45^\circ$ fiber bundles




Sample

Mounted Sample




X-ray projection



Monitoring sets of X-ray projections



Laminate with $\pm 45^\circ$ fiber bundles




Sample

Mounted Sample




X-ray projection



Monitoring sets of X-ray projections



Laminate with $\pm 45^\circ$ fiber bundles




Sample

Mounted Sample




X-ray projection



Monitoring sets of X-ray projections



Laminate with $\pm 45^\circ$ fiber bundles




Sample

Mounted Sample




X-ray projection



Monitoring sets of X-ray projections



Laminate with $\pm 45^\circ$ fiber bundles



Sample

Mounted Sample

X-ray projection





Sample Overview

Sample Nr.	Fiber architecture	Chemical composition
1	UD-single bundle	Al ₂ O ₃ -fiber, mullite matrix (3Al ₂ O ₃ 2SiO ₂ or 2Al ₂ O ₃ SiO ₂)
2	UD- laminate as processed (1300°C, 1h)	Al ₂ O ₃ -fiber and matrix; as processed
3	UD- laminate aged (1450°C, 1h)	Al ₂ O ₃ -fiber and matrix; aged
4	+/- 45° laminate, aged	Al ₂ O ₃ -fiber and matrix



Unidirectional fiber bundle embedded in porous matrix Al_2O_3 – fibers and Mullite matrix




As processed: sintered 1h at 1300°C

Shrinkage cracks visible and good separation between fibers and matrix




Unidirectional fiber bundle embedded in porous matrix

Al_2O_3 – fibers and Mullite matrix



Shrinkage cracks due
to processing





Fibers, matrix not shown



Unidirectional WHIPOX™ - Laminate


Al_2O_3 – fibers and matrix (aged 1h at 1450°C)




Pores in sub - millimeter range, matrix rich regions between fiber bundles, shrinkage cracks in matrix, difficult separation between fibers and matrix



Difference between as processed and aged




As processed – few matrix cracks




Aged – abundant matrix cracks



Laminate with +/- 45° layers (Al₂O₃-fibers and matrix)



Laminate with +/- 45° layers (Al₂O₃-fibers and matrix)






Aged at
1450°C for 1 h

Ø 1,6 mm

Fiber bundles, sub – millimeter pores, shrinkage cracks, fiber bundle cross lines




Laminate with +/- 45° layers (Al₂O₃-fibers and matrix)



Aim: parametric description of cross line geometry
(fiber flexure, spatial fiber – matrix distribution)

Challenge: Difficult fiber separation in all alumina CMC



Laboratory X-ray tomography for high resolution





Illustration by XRadia inc., now Zeiss




X-ray tomography with laboratory devices: Porous Matrix of CMC




Cross section image by
scanning electron microscope


Slice of 3d-reconstruction
from X-ray projections



From reconstructed X-ray data to Finite Element Model




Reconstructed sample volume




Cropped volume for analysis


From reconstructed X-ray data to Finite Element Model




Cropped volume




Segmented pores




Segmented ZrO₂ particles



Surface model



Meshed surface




2µm edge length



Meshed volume



Import of 3d-image into Numerical Calculation Tool






Exemplary virtual mechanical experiment






Generating compressive stress by displacement of top plane



Exemplary virtual mechanical experiment



Exemplary virtual mechanical experiment




Tomography based on FIB-Slices





FIB: Focused ion beam

SEM: Scanning electron microscope

Generating 2d-slices by ion beam cutting and subsequent recording SEM-images




Generating a 3d – image of porous ceramic




- alignment
 - scaling
 - cropping
 - segmentation
- ➔ 3D-Volume





Generating a 3d – image of porous ceramic II



Challenge: segmentation of
pores and matrix due to
information from underlying
planes



Porosity from 3d-images and by Archimedes method



Method for porosity measurement	Porosity %	ZrO ₂ -Vol. %
X-ray tomography	35 - 36	2-3
FIB-slice tomography	35,4	2,8
Archimedes	36,1	-



Summary and Outlook

- X-ray tomography can provide excellent 3d-images of microstructures down to sub-micron range
 - Non destructive technique
 - Using high energy synchrotron X-ray radiation provides unique options:
 - Short acquisition time
 - No (severe) restriction of sample size for high resolution images
 - Acquisition at high temperature possible
 - Acquisition under mechanical load (in-situ testing)
 - Using laboratory devices with x-ray point source (and additional x-ray optics) allows high resolution but sample size is restricted (ca. 50µm)
- Slice and view technique using focus ion beam and scanning electron microscope allows higher resolution
 - But no in situ acquisition at high temperatures or under load
 - Possibility of generating artefacts when slicing
 - Challenge: porous samples, showing in each slice information from underlying material



Summary and Outlook II

- Data from X-ray tomography and slice and view techniques can be used for generating numerical microstructure models
- Virtual experiments can be done with Finite Element software
- Image analyses can be used to identify geometry parameters of the microstructure, which allow for generating virtual microstructures
 - Parameter studies for elucidating the microstructure - property relationship



Thank to co authors and other colleagues who have contributed to the presented results:

DLR-Institute of Materials Research in Cologne:

S. Hackemann, K. Kelm, M. Schmücker, J. Wischek

Department Mechanical and Aerospace Engineering, University of Central Florida, Orlando, Florida:

S. Raghavan, S. Sofronsky

Fenn College of Engineering, Cleveland State University, Ohio:

C. Lacdao

Advanced Photon Source, Argonne National Laboratory, Argonne, Illinois:

J. Almer and J. Okasinski



Thank you for your attention!

Questions?

Acknowledgements:

- This material is based upon work supported by the National Science Foundation Grants OISE 1157619 and CMMI 1125696
- German Aerospace Center – aeronautic research program
- Use of the Advanced Photon Source, an Office of Science User Facility operated for the U.S. Department of Energy (DOE) Office of Science by Argonne National Laboratory, was supported by the U.S. DOE under Contract No. DE-AC02-06CH11357.

