

A low-angle, upward-looking photograph of a parabolic trough solar collector. The image shows the complex metal framework and the long, curved mirrors (collectors) that reflect sunlight. The sky is a clear, vibrant blue. The perspective creates a sense of height and scale.

Silicone based HTF in parabolic trough applications – from lab to loop

2018 10 03, SolarPACES
Erich Schaffer, Wacker Chemie AG

Content

- ▶ **Introduction Wacker Chemie AG**
- ▶ **HELISOL[®] 5A: chemical and physical parameters**
- ▶ **HELISOL[®] 5A: operational safety**
- ▶ **HELISOL[®] 5A: USP's & Proof of Concept**

WACKER at a Glance


Wacker Chemie AG

- ▶ Founded in 1914 by Dr. Alexander Wacker
- ▶ Headquartered in Munich


WACKER Group (2017)

- ▶ Sales: €4.92 billion
- ▶ EBITDA: €1,01 million
- ▶ R&D: €153 million
- ▶ Investments: €327 million
- ▶ Employees: 13,811

Sales 2017: €4.92 bn




60% of Sales Outside Europe



Content

- ▶ Introduction Wacker Chemie AG
- ▶ **HELISOL[®] 5A: chemical and physical parameters**
- ▶ HELISOL[®] 5A: operational safety
- ▶ HELISOL[®] 5A: USP's & Proof of Concept

New HTF needed to break the 400°C temperature barrier



Benchmark HTF

- ▶ Biphenyl-Diphenyloxide (BP/DPO)
- ▶ Max. process temp.: 400°C
- ▶ Freeze point: 12°C


HTF requirements

- ▶ High thermal stability
- ▶ Good heat transfer
- ▶ Low freeze point
- ▶ Low vapor pressure
- ▶ No critical degradation products
- ▶ Low fire risk
- ▶ Low cost


HELISOL[®] 5A shows advantages over BP/DPO

BP/DPO*

- ▶ 25 - 28% BP, 72 - 75% DPO
(Diphyl[®], Dowtherm[®] A, Therminol[®] VP-1)



Biphenyl; Diphenyl




Diphenylether

- ▶ Working temp.: 60°C bis 395°C
- ▶ Freezing point: 12°C
- ▶ Vapor pressure (400 °C): 11 bar
- ▶ Self ignition temp.: 599°C

*BP/DPO (Biphenyl/Diphenyloxid)

HELISOL[®] 5A

- ▶ Low viscosity polydimethylsiloxane,
- ▶ Multi-component mixture of molecules



- ✔ Working temp.: -40°C to 425°C
- ✔ Pour Point: -65°C
- ✔ No freeze protection
- ▶ Vapor pressure (400 °C): 16 bar
- ▶ Self ignition temp.: 367°C
- ✔ Lower H₂-formation
- ✔ No Fouling

HELISOL[®] development - from Lab to Loop



**Pre-
Assessment**

HELISOL[®] 5A

- higher thermal stability
- no freezing
- lower hydrogen formation

Lab-Scale (TRL* 4)



multigram scale

aging kinetics (autoclave + oven)

degradation / compatibility

*TRL = technology readiness level

HELISOL[®] development - from Lab to Loop



HELISOL[®] 5A

- higher thermal stability
- no freezing
- lower hydrogen formation

Technical-Scale (TRL 5)




HTF volume 0.5 m³

operation parameters:

- ▶ 300°C, 15 bar

*TRL = technology readiness level

HELISOL[®] development - from Lab to Loop



HELISOL[®] 5A

- higher thermal stability
- no freezing
- lower hydrogen formation

Loop-Scale (TRL 7)




HTF volume 8 m³

Proof of Concept

- ▶ 1200 h solar
- ▶ up to 450°C, 23 bar

*TRL = technology readiness level

HELISOL[®] development - from Lab to Loop



HELISOL[®] 5A

- higher thermal stability
- no freezing
- lower hydrogen formation

HELISOL[®] XA

- lower vapor pressure
- useable for existing plants

Loop-Scale (TRL 7)




HTF volume 8 m³

Proof of Concept

- ▶ 1200 h solar
- ▶ up to 450°C, 23 bar


*TRL = technology readiness level

Lab-Scale Thermal Stability Evaluation




- ▶ lab-scale degradation and life-time analysis
- ▶ confirmation of data values at loop-scale
(test facilities in China / Spain)

What is the temperature limit of HELISOL[®] 5A?




HELISOL[®] 5A offers a lower long term hydrogen formation



HTF reworking- and gas separation concept easy to apply


Reworking Concept

- ▶ Viscosity is kept constant via HTF exchange
- ▶ No Ullage system needed



Gas Separation Concept

- ▶ Degradation products: H_2 , CH_4 , C_2H_6 , Silane
- ▶ Flashing → partial condensation → refeed



Content

- ▶ Introduction Wacker Chemie AG
- ▶ HELISOL[®] 5A: chemical and physical parameters
- ▶ **HELISOL[®] 5A: operational safety**
- ▶ HELISOL[®] 5A: USP's & Proof of Concept

Spray Ignition tests with aged HTF (TÜV) shows no disadvantage of HELISOL[®] 5A

► BP/DPO: fire at 2-3m distance

► HELISOL[®] 5A: fire at 1m distance



Spray ignition test: ISO 15029

No self ignition of HELISOL[®] 5A at small scale Release Tests


► 1/4" – 430 °C 15 bar -> **No self-ignition**



Full Scale Release Test (at PSA)

Setup



- ▶ Fast opening / closing release valve (0.2 sec)
- ▶ Different nozzles: $\frac{1}{4}$ ", 1", 2"



2" release test performed in May 2018 at the PSA



Full Scale Release Test - Temperature Contribution



IR Camera

Content

- ▶ Introduction Wacker Chemie AG
- ▶ HELISOL[®] 5A: chemical and physical parameters
- ▶ HELISOL[®] 5A: operational safety
- ▶ **HELISOL[®] 5A: USP's & Proof of Concept**

HELISOL[®] 5A: Up to 5 % LCOE* Reduction Potential

$$\text{LCOE} = \frac{\text{CRF}^{**} * \sum \text{CAPEX} + \sum \frac{\text{OPEX}}{\text{Year}}}{\frac{\text{Revenue}}{\text{Year}}}$$

Revenue (electricity sold)

- + Working temperature: - 40°C to 425 °C

CAPEX

- + Reduced TES*** cost
- + No freeze protection
- + Filling at any time (temperature independent)
- + No Ullage needed for viscosity control
- Higher vapor pressure to be considered

OPEX

- + No recirculation for freeze protection
- + Maintenance at any time
- + Less pump energy (low viscosity)
- + Shorter start up period
- + Lower degradation/exchange rate at same temperature
- + Lower H₂ generation
- + No fouling

*LCOE: Levelized cost of electricity, **CRF: Capital recovery factor, ***TES: Thermal Energy Storage

Proof of Concept for HELISOL® 5A at independent Demo-Loops



PSA: (2016-2019)

- ▶ ~1300h solar operation
- ▶ Proof of Concept at 425°C / 520h
- ▶ overheating: 435°C to 450°C / 50h



by courtesy of Royal Tech

Inner Mongolia (CN): Royal Tech Demo-Loop

- ▶ Operating at 425°C since April 2016
 - ▶ ~1800h above 400°C
 - ▶ ~850h between 400°C to 430°C
 - ▶ overheating up to 470°C
- ▶ 50 MW YUMEN (China) project to be realized with HELISOL® 5A

Summing up

- ▶ **HELISOL® 5A offers extremely broad operating temperature range**
- ▶ **Up to 5 % LCOE reduction potential**
- ▶ **Proof of Concept done - HELISOL® 5A is used already as HTF**
- ▶ **Strategic partnership agreement with Royal Tech (CN) for 50MW YUMEN project**

With HELISOL® 5A it is possible to realize a parabolic trough plant with a working temperature above 400°C

The authors would like to thank the
German Federal Ministry of Economic Affairs and
Energy
for the funding of the projects
Si-HTF, SITEF and SIMON
and their cooperation partners

Supported by:



Federal Ministry
for Economic Affairs
and Energy

on the basis of a decision
by the German Bundestag

