

Monitoring soils using satellite images

Products of the Soil Composite Mapping Processor (SCMaP)

Uta Heiden (DLR), Simone Zepp (DLR / LMU Munich), Marianne Jilge (DLR), Anne-Katrin Metz Marconcini (DLR), Julian Zeidler (DLR), Thomas Esch (DLR), Derek Rogge (Hyperspectral Intelligence)

GIZ - Interactive Expert Brainstorming Session
28.04.2020



Knowledge for Tomorrow



Optical EO for soil organic carbon monitoring – Potentials and Challenges

- Optical Earth Observation (EO) allow the estimation of soil organic carbon (SOC)
- SOC can only be estimated from the visible upper soil layer, soil depth measurement not possible with optical EO
- Operational soil monitoring system is currently requested by the European Space Agency – proposals in development
- Sensibility of operational SOC monitoring systems do not coincides with the reporting requirements of 1 year
- Soil moisture can be estimated by active and passive microwave technology, operational daily soil moisture product available at 0,25° grid cell size
- Requires special techniques for satellite image analyses (see following slides) to prepare a suitable data base

Loss of A and B horizons
due to erosion in Spain

Photo: T. Schmid Sutter (CIEMAT)



Soil Composite Mapping Processor (SCMaP) – Main Idea


Soil exposure vary over time (example RapidEye, 2012)



April
20.5 %



May
17.5 %






July
13.8 %



August
26.8 %





September
25.8 %





Expanding data base
Bare Soil Exposure = 47.9 %

SCMaP Product suite for soil monitoring







Soil Reflectance Composites

Additional Information on Land Cover Dynamics



Statistics




SCMaP Product suite for soil monitoring

Soil Reflectance
Composites

Additional
Information on
Land Cover
Dynamics

Statistics

Products available
for different time
periods




SCMaP
**Product
suite for
soil
monitoring**

Soil Reflectance
Composites


Additional
Information on
Land Cover
Dynamics

Statistics


Products available
for different time
periods



Product suite for soil monitoring




Around Harz Mountains, Germany (RGB Landsat 7-5-3)









BÜK 1000 - Soil Map of Germany


Product suite for soil monitoring




Harz Mountains, Germany


Soil units World Reference Base (WRB) for Soil Resources: Examples

- | | | |
|---|---|--------------------------|
| 1 |  | Haplic Chernozem (Chha) |
| 2 |  | Calcaric Cambisol (CMca) |
| 3 |  | Dystric Cambisol (CMdy) |
| 4 |  | Haplic Luvisol (LVha) |
| 5 |  | Dystric Gleysol (GLdy) |
| 6 |  | Eutric Histosol (HSeu) |





BÜK 2000 (German Soil Map)





0 40 [%]

SCMaP

Product suite for soil monitoring

Soil Exposure frequency [%]

- Areas prone to soil erosion



0 15 [Count]

SCMaP



Product suite for soil monitoring

Soil Exposure frequency [%]

- Areas prone to soil erosion


Vegetation frequency [Count]

- Intensity of use









Potential Application

Exposed soil coverage and simple landcover change




Exposed soil coverage and simple landcover change - Validation



- Statistical Data from DESTATIS (German Federal Statistical Office)
- Exclusion of permanent grassland)
- 1999, 2001, 2003, 2007, 2010
- Comparison on county level

Current SCSMaP processing status



Country	Downloaded	Pre-processed
Germany	20,318	11,438
Bulgaria	5,561	5,383
Romania	9,550	8,915
Czech Republic	3,260	2,943
Iberian Peninsula	18,938	18,755
Italy	16,067	12,434
Sweden	12,453	proc.
Greece	proc.	proc.
Ireland	proc.	proc.
France	proc.	proc.

Thank you for your attention!

German Aerospace Center (DLR)

Contact: uta.heiden@dlr.de

