

In-Situ Diagnostic Methods for SOFC

G. Schiller, K.A. Friedrich, M. Lang, P. Metzger, N. Wagner

German Aerospace Center (DLR), Institute of Technical Thermodynamics,
Pfaffenwaldring 38-48, D-70569 Stuttgart, Germany

International Symposium on Diagnostic Tools for Fuel Cell Technologies,
Trondheim, Norway, June 23-24, 2009



Outline

- Introduction
- Electrochemical Impedance Spectroscopy on Stacks
- Spatially Resolved Measurements: Current density
 - Voltage
 - Impedance
 - Temperature
 - Gas Composition
- Optical Spectroscopy
- X-Ray Tomography
- Conclusion





Investigation of Degradation and Cell Failures

- Insufficient understanding of cell degradation and cell failures in SOFC
- Extensive experimental experience is not generally available which would allow accurate analysis and improvements
- Long term experiments are demanding and expensive
- Only few tools and diagnostic methods available for developers due to the restrictions of the elevated temperatures



Conventional Test Stand Diagnostics

- **Conventional test stand diagnostics:** provide important and essential information about fuel cell performance and behaviour:
 - $U(i)$ characteristics, OCV...
 - EIS on single cells
 - Current interrupt methods
 - Performance degradation with time $U(t)$; $i(t)$...
 - Cell voltage distribution $U_{\text{stack}} = U_1 + U_2 + U_3 \dots$
 - Pressure loss / Gas tightness test
 - Gas utilization measurement
 - Temperature distribution and control





„Sophisticated“ (non-traditional) in-situ Diagnostics

- Electrochemical impedance spectroscopy on stacks
- Spatially resolved measuring techniques for current, voltage, temperature and gas composition
- Optical imaging
- Optical spectroscopy
- Acoustic emission detection
- X-ray tomography





Challenges for EIS for Stack Investigations


- Large areas (e.g. 100 cm²) lead to high current and low impedances of about 1 mOhm.
- Electrochemical processes appear at high frequencies (up to 100 kHz) due to the high reaction rates at high temperatures.
- Stacks generally contain metallic components leading to high frequency disturbances.
- Contacting of all cells and sensing in specific cells does not account for the voltage distribution in the stack.
- The sensor wires are at high temperatures: an optimization of the measurement system is not possible during operation.
- Strong overlapping of electrode processes; evaluation with equivalent circuits can be inaccurate.
- For system with current > 40 A no commercial equipment available.



Mitigation of EIS Problems


- Reduction of the high frequency disturbances by optimization of the wiring of the electrical sensing of the SOFC stack.
- Variation of the operating conditions (gases, temperature) in order to determine the different impedances of the electrode processes
- Modeling of the spectra by an equivalent circuit.
- Development of advanced EIS equipment for high currents / high frequencies in corporation with instrument manufacturer (Zahner Elektrik GmbH).

Experimental Set-up for EIS Measurements of Stacks at DLR




Performance of the 5-Cell Short Stack at 750°C

(5 H₂+5 N₂+3%H₂O / 20 air (SLPM), 94 h)




Nyquist Plot of one Cell of a 5-Cell Short Stack at Different Current Densities

(750°C, 2.5 H₂+2.5 N₂ / 20 air (SLPM), 142 h)






Equivalent Circuit for the Fitting of the Impedance Spectra





Voltage Losses at one Cell of a 5-cell Short Stack at Different Current Densities

(750°C, 2.5 H₂+2.5 N₂ / 20 air (SLPM), 142 h)









Motivation

- Strong local variation of gas composition, temperature, current density
- Distribution of electrical and chemical potential dependent on local concentrations of reactants and products

- Reduced efficiency
- Temperature gradients
- Thermo mechanical stress
- Degradation of electrodes




Measurement Setup for Segmented Cells




- 16 galvanically isolated segments
- Local and global i-V characteristics
- Local and global impedance measurements
- Local temperature measurements
- Local fuel concentrations
- Flexible design: substrate-, anode-, and electrolyte-supported cells
- Co- and counter-flow

Cell design and Testing Station






From a „simple“ cell design
with manually controlled
features



GC measurement

Assembly and contacts




- All cell concepts
- Improved contacting
- Reliable assembly
- Impedance measurement
- Temperature measurement

Flexible housing, impedance spectra with reduced interferences



Deutsches Zentrum
für Luft- und Raumfahrt e.V.
in der Helmholtz-Gemeinschaft

Schematic Lay-out of the Electrical Circuit of the Segmented Cell Configuration



Internal cell resistances:
 $R_{i,j}$,



Resistances of the wires
contacting the anode:
 $R_{LA,j}$

Resistances of the wires
contacting the cathode:
 $R_{LK,j}$

Only segments 1, 2, 3, 16
are illustrated

OCV Voltage Measurement for Determination of Humidity

- Voltage distribution at standard flow rates:
- 48.5% H₂, 48.5% N₂ + 3% H₂O, 0.08 SlpM/cm² air




Nernst equation:

$$U_{rev} = U_{rev}^0 - \frac{RT}{zF} \ln \left(\frac{p_{H_2O}}{\sqrt{p_{O_2} p_{H_2}}} \right)$$

Produced water:

S4: 0.61%, S8: 0.72%,
S12: 0.78%, S16: 3.30%


Variation of Load - Reformate



Anode supported cell, LSCF cathode, 73,96 cm², gas concentrations (current density equivalent): 54.9% N₂, 16.7% H₂, 16.5% CO, 6.6% CH₄, 2.2% CO₂, 3.2% H₂O (0.552 A/cm²), 0.02 SlpM/cm² air




Reformate: Changes of the Gas Composition at 0 mA/cm²






Alteration of the gas composition at 435 mA/cm²




Combined Experimental and Modeling Approach

Objectives of the study:

- Better understanding of the local variations
 - Identification of critical conditions
 - Optimisation of cell components



Experiments on single segmented SOFC




Electrochemical model of local distributions



Potential for Optical Spectroscopies

a) *In situ* microscopy


b) *In situ* Raman laser diagnostics





- Raman spectroscopy
- Laser Doppler Anemometry (LDA)
- Particle Image Velocimetry (PIV)
- Fast-Fourier Infrared (FTIR)
- Coherent Anti-Stokes Raman Spectroscopy (CARS)
- Electronic Speckle Pattern Interferometry (ESPI)




Tomography Diagnosis of PEM Fuel Cells



in-situ synchrotron
radiography



neutron
tomography



in-situ neutron
radiography

Investigation of water management under operating conditions



Deutsches Zentrum
für Luft- und Raumfahrt e.V.
in der Helmholtz-Gemeinschaft




X-Ray Tomography (CT) Facility at DLR



X-Ray CT Facility v|tome|x L450 at DLR Stuttgart

3 dimensional non intrusive
imaging of SOFC cassette





Summary

- The operating conditions (elevated temperature) reduce significantly the possibilities for in-situ SOFC diagnostic methods.
- EIS will remain the main diagnostic probe of the state of SOFC.
- Non-traditional in-situ diagnostics methods can provide additional important information:
 - Spatially resolved measurements to obtain local distribution of cell properties (current, voltage, impedance, gas composition, temperature)
 - Combined analytical and modeling approach
- Large future potential for optical spectroscopies (e.g. Raman spectroscopy) and x-ray tomography.