


Development and Characterisation of Metal-Supported Solid Oxide Fuel Cells

G. Schiller


**German Aerospace Center (DLR)
Institute of Technical Thermodynamics**

**9th International Symposium on Advances in Electrochemical Science and Technology (ISAEST-9),
December 2-4, 2010, Hotel Green Park, Chennai, India**




Outline


- Introduction
 - German Aerospace Center (DLR)
 - SOFC Activities at DLR
- Development of Metal Supported SOFC Concept of DLR
 - Development of Functional Layers and Cells
 - Electrochemical Cell Performance
- Advanced Characterisation Techniques
 - Spatially Resolved Cell Characterisation
 - New Imaging Methods for SOFC Characterisation
- Conclusions



DLR German Aerospace Center



- Research Institution
- Space Agency
- Project Management Agency





Locations and Employees

6700 employees across
33 institutes and facilities at

■ 13 sites.

Offices in Brussels,
Paris and Washington.






Research Areas

- Aeronautics
- Space
- Transport
- Energy
- Space Agency
- Project Management Agency





DLR Site Stuttgart

Employees: 560

Size of site: 25 860 m²

Research institutes:

- Institute of Structures and Design
- Institute of Vehicle Concepts
- Institute of Technical Physics
- Institute of Technical Thermodynamics
- Institute of Combustion Technology





Institute of Technical Thermodynamics

Prof. Dr. Dr.-Ing. *habil* H.Müller-Steinhagen

Solar Research

Prof. Dr.-Ing. R. Pitz-Paal

Electro-Chemical Energy Technology

Prof. Dr.rer.nat. A. Friedrich

Thermal Process Technology

Dr.rer.nat. R.Tamme

Systems Analysis and Technology Assessment

Dr.-Ing. W. Krewitt

Administration and Infrastructure

Dipl.-Wirt.Ing. J. Piskurek


Logistics & Purchasing

Project Administration


Computing Support

Workshops







Development of Metal Supported Cells (MSC)






Characterization of Short Stacks and Stacks (ASC, MSC)



SOFC Modeling

System Technology


SOFC Diagnostics






Development of Metal Supported Cells


ESC




ASC



ASC



MSC




Improved power density

Improved long-term stability

Reduced operating temperature

Advantages of MSC:

- High robustness
- High resistance against thermal and redox cycling
- Good integration into interconnects (bipolar plates)
- Low cost of metal support and cell materials (thin layers)



SOFC Metal Supported Cell



Plasma Deposition Technology

Thin-Film Cells


Ferritic Substrates and Interconnects

Compact Design with Thin Metal Sheet Substrates


Brazing, Welding and Glass Seal as Joining and Sealing Technology




(not in scale)





Vacuum Plasma Spraying of SOFC Cells









Plasma Spray Laboratory at DLR Stuttgart








Powders Used for the Spraying of the Cells

Powder	NiO	ZrO₂- 7 mol %Y₂O₃	ZrO₂- 10 mol%Sc₂O₃	(La_{0.8}Sr_{0.2})_{0.98} MnO₃
Short name	NiO	YSZ	ScSZ	LSM
Morphology	sintered, crushed	sintered, crushed	sintered, crushed	sintered, spherical
Size distribution	10-25 μm	5-25 μm	2-35 μm	20-40 μm
Supplier	Cerac, USA	Medicoat, Switzerland	Kerafol, Germany	EMPA, Switzerland







Morphology of Porous Metal Substrate PM Fe-26Cr-(Mo,Ti,Mn,Y₂O₃) of Plansee SE




Metallographic Cross Section of MSC Cell






Stack Assembly Based on Metal Supported Cell



Plasma-sprayed cell with sealing by laser welding




1 = Metallic lower plate
2 = Active cell on substrat
3 = Metallic frame

4 = Cassette

5 = Stack





Stack Assembly Based on Metal Supported Cell



Current MS-SOFC Repeat Unit

90x120 mm² footprint – ca 100 cm² cell area

Counter flow design

Stamped sheet ferritic steel bipolar plate


Welded Fe-Cr substrate




+ (A)



=




+ (B)




(C)






Performance of Plasma Sprayed Metal Supported Cell



MSC Cell


12.5 cm² cell at 800°C; H₂/N₂ and Air



3-Cell Stack


100 cm² single cells at 800°C; H₂/N₂; Air

Thermal Cycling




- 15 thermal cycles performed, 12 down to 350 °C and 3 to ambient temperature
- Degradation after thermal cycles was 10.3 %

Redox Cycling




- 20 forced redox cycles performed with 50 ml/min O₂ on the anode side per layer
- Increase of power density after 5 cycles
- Degradation of the stack was 9.1 % after 20 redox cycles




Investigation of Degradation and Cell Failures

- Insufficient understanding of cell degradation and cell failures in SOFC
- Extensive experimental experience is not generally available which would allow accurate analysis and improvements
- Long term experiments are demanding and expensive
- Only few tools and diagnostic methods available for developers due to the restrictions of the elevated temperatures



„Sophisticated“ (non-traditional) In-situ Diagnostics

- Electrochemical impedance spectroscopy on stacks
- Spatially resolved measuring techniques for current, voltage, temperature
- and gas composition
- Optical imaging
- Optical spectroscopy
- Acoustic emission detection
- X-ray tomography




Motivation for Spatially Resolved Cell Characterisation

Problems:

- Strong local variation of gas composition, temperature, and current density



This may lead to:

- Reduced efficiency
- Thermomechanical stress
- Degradation of electrodes





Effects are difficult to understand due to the strong interdependence of gas composition, electrochemical performance and temperature

Measurement Setup for Segmented Cells




- 16 galvanically isolated segments
- Local and global i-V characteristics
- Local and global impedance measurements
- Local temperature measurements
- Local fuel concentrations
- Flexible design: substrate-, anode-, and electrolyte-supported cells
- Co- and counter-flow

Modelling and Simulation




- Electrochemistry: Elementary kinetics
- Porous electrodes: Mass and charge transport
- Channels: Transient Navier-Stokes conservation equations (Mass, momentum, particles, energy)
- Interconnects: energy conservation




Segmented Cells

- Anode supported cells:
Segmented cathode
(H.C.Starck/InDEC)





- Electrolyte supported cells:
Segmented cathode and anode







Test Rig





OCV Voltage Measurement for Determination of Humidity

- Voltage distribution at standard flow rates:
- 50% H₂, 50% N₂ + 3% H₂O, 0.08 SlpM/cm² air




Nernst equation:


$$U_{rev} = U_{rev}^0 - \frac{RT}{zF} \ln \left(\frac{P_{H_2O}}{\sqrt{P_{O_2} P_{H_2}}} \right)$$

Produced water:

S4: 0.61%, S8: 0.72%,
S12: 0.78%, S16: 3.30%



Power Density Distribution under Conditions of High Fuel Utilisation



Counter-flow

Anode: 33% H₂, 1% H₂O,
66% N₂


Cathode: air

T = 800 °C

Cell voltage: 0.59 V


F_u = 80%

Lit.: Fuel Cells, 10 (3), 411-418 (2010)




Assessment of Local Performance with Segmented SOFCs

➤ Experiment




16 segments


➤ Model



Global behavior




Local behavior




Cell can be locally in critical conditions!


Variation of Load - Reformate




Anode supported cell, LSCF cathode, 73,96 cm², gas concentrations (current density equivalent): 54.9% N₂, 16.7% H₂, 16.5% CO, 6,6% CH₄, 2,2% CO₂, 3,2% H₂O (0.552 A/cm²), 0.02 SlpM/cm² air




Alteration of the Gas Composition at 435 mA/cm²







Alteration of the Gas Composition at 100 mA/cm²



Potential for Optical Spectroscopies





- Raman spectroscopy
- Laser Doppler Anemometry (LDA)
- Particle Image Velocimetry (PIV)
- Fast-Fourier Infrared (FTIR)
- Coherent Anti-Stokes Raman Spectroscopy (CARS)
- Electronic Speckle Pattern Interferometry (ESPI)




Setup for 1D-Raman Spectroscopy

- 3 double pulse Nd:YAG PIV 400 laser systems
- $\lambda = 532 \text{ nm}$
- Repetition rate: 10 Hz
- Single pulse: $E \leq 350 \text{ mJ} / \sim 7 \text{ ns}$
- Pulse energy: 6 x 300 mJ
- Pulse length: $\sim 380 \text{ ns}$
- (temporal resolution)







Transparent Flowfield for SOFC



Top view




Side view





Experimental Setup for Raman Spectroscopy Measurements






Cell Housing with Transparent Flowfield in Hot Furnace






Preliminary Results




➤ H₂ + 3% H₂O

➤ 850 °C

- Large scatter in detected signal
- Improvement of S/N ratio needed




Preliminary Results




➤ H₂ + 3% H₂O
➤ 850 °C

- Measurements and evaluation still in progress
- Tendencies of the species concentration profiles can be seen



Setup for In-Situ Optical Microscopy






Conclusions


- The development of the metal supported SOFC concept has a high potential for SOFC application in dynamic operation with multiple thermal and redox cycles
- Scale-up to a full size cassette with adequate cell performance is under way
- In-situ diagnostic techniques allow for a largely extended insight into fuel cell processes
- The obtained experimental data using a segmented cell setup that allows for the measurement of local i-V characteristics, gas composition and temperature can be used for modeling and simulation
- Strong gradients of gas concentrations and current density particularly at operation with high fuel utilisation may result in locally critical operating conditions
- Additional in-situ diagnostic methods such as optical microscopy and gas-phase Raman Spectroscopy can provide further information for the understanding of cell reactions and processes



Acknowledgment

- I'd like to thank my colleagues who contributed to this presentation:
 - Asif Ansar
 - Corinna Auer
 - Holger Ax
 - Wolfgang Bessler
 - Claudia Christenn
 - Patric Szabo
 - Caroline Willichand all co-workers in our Department „Electrochemical Energy Technology“
- Financial support from German Federal Ministry of Economics and from State Ministry of Baden-Württemberg is gratefully acknowledged.





Locally Resolved Power Density Distribution and Fuel Utilisation in Dependence of H₂ Concentrations

