

# EIS in Fuel Cell Science

**Dr. Norbert Wagner**  
**German Aerospace Center (DLR)**  
**Institute for Engineering Thermodynamics**  
**Pfaffenwaldring 38-49, 70569 Stuttgart, Germany**

**Electrochemical Impedance Spectroscopy**  
**Fundamentals and Applications**  
**5.-6. November 2015**  
**Frankfurt am Main**



Knowledge for Tomorrow



## Presentation outline

- Introduction
  - Motivation
  - Types of Fuel Cells
  - Experimental set-up for different types of FCs
- Microstructure of fuel cells and modeling of fuel cells with equivalent circuits
- Impedance models of porous electrodes
- Different applications of EIS in FC research
  - Contributions to performance loss of PEFC
  - Degradation mechanism of PEFC
  - Time dependent EIS
    - CO poisoning of PEFC-anodes
    - Flooding of PEFC cathodes
  - EIS measured on Ag-Gas Diffusion Electrodes (GDE) during Oxygen Reduction in alkaline electrolyte (AFC)
  - EIS measured at fuel cell stack (SOFC)
- Conclusion




## Motivation

### Characterization of Fuel Cells by Electrochemical Impedance Spectroscopy:

- Determination of electrode **structure** and reactivity, separation of electrode structure from electrocatalytically activity
- Determination of reaction mechanism (**kinetic**) and separation of different overvoltage contributions to the fuel cell performance loss
- Determination of **degradation** mechanism of electrodes, electrolyte and other fuel cell components (bipolar plates, end plates, sealings, etc.)
- Determination of optimum **operation condition** (e.g. gas composition, temperature, partial pressure), cell design (flow field) and stack design




### Schematic representation of main types of fuel cells




# Experimental set up and cells used for EIS

Segmented and single PEFC cell (polymer electrolyte)

Fuel „half“ cell with liquid electrolyte



Test cell for SOFC (short stack) (Solid Oxide Electrolyte)



## Fuel cell overvoltage and current density / voltage characteristic

Hydrogen Oxidation Reaction (HOR):

$$\eta_{H_2} = RT/2F \ln(i/i^*)$$

Oxygen Reduction Reaction (ORR):

$$\eta_{O_2/air} = RT/[(1-\alpha)2F] [\ln i - \ln i^*]$$

Ohmic loss


$$\eta_{\Omega} = iR$$

Transport limitation (diffusion)


$$\eta_d = -RT/2F \ln(1 - i/i_{lim})$$

Fuel cell voltage


$$U_c = U_0 - \eta_{ct,H_2} - \eta_{ct,O_2/air} - \eta_d - \eta_{\Omega}$$



## Electrochemical Impedance Spectroscopy: Application to Fuel Cells




## Schematic diagram of the U-i characteristic of PEFC and Electrochemical Impedance






## Schematic representation of the different steps and their location during the electrochemical reactions as a function of distance from the electrode surface





N. Wagner, K.A. Friedrich, *Dynamic Response of Polymer Electrolyte Fuel Cells* in „Encyclopedia of Electrochemical Power Sources“ (Ed. J. Garche et al.), ISBN-978-0-444-52093-7, Elsevier Amsterdam, Vol.2, pp. 912-930, 2009



## Overview of the wide range of dynamic processes in FC



## Bode representation of EIS measured at different current densities, PEFC operated at 80°C with H<sub>2</sub> and O<sub>2</sub> at 2 bar




N. Wagner in „Pem Fuel Cell Diagnostic Tools“, Haijaing Wang, Xiao-Zi Yuan, Hui Li (Eds.), 2011




## Field of application of porous electrodes

Water purification and treatment  
(Bio)-Organic synthesis




Fuel Cells




Batteries and supercaps




Electrolysis (Water, NaCl, etc.)



## PEFC: Schematic Diagram (cross section)




## Common Equivalent Circuit for Fuel Cells







## SEM micrograph of PEFC electrode (Pt/C+PTFE)



## TEM micrograph of Carbon Supported Platinum Catalyst




## SEM picture of PTFE/C powder



## Field of application of porous electrodes

Water purification and treatment  
(Bio)-Organic synthesis





Batteries and supercaps





Electrolysis (Water, NaCl, HCl, etc.)

Fuel Cells





## Nyquist representation of Impedance of RC-transmission line, model of a flooded pore



$$R = 3 \Omega$$

$$C = 0.5 \text{ F}$$

$$Z(i\omega) = \sqrt{\frac{R}{i\omega C}} \coth \sqrt{i\omega RC}$$

$$R_0 = R/3 = \delta L / 3\pi r^2$$

$\delta$  = specific electrolyte resistance

$r$  = pore radius


$L$  = pore length



## Simple pore model with faradaic processes in pores

### RC-transmission line of a flooded pore

R. De Levie, Electrochim. Acta, 8(1963) 751





$r$  = electrolyte resistance inside the pore per unit length

$c$  = interface capacitance per unit length

$r_{ct}$  = interface charge transfer resistance per unit length



## Nyquist representation of porous electrode impedance with faradaic impedance element





$$r = 3\ \Omega$$

$$c = 500\ \text{mF}$$

$$r_{\text{ct}} = 1.5\ \Omega$$




## Thin-film model and agglomerate plus thin-film model of a porous electrode



I.D. Raistrick, *Electrochim. Acta*, **35**(1990) 1579




## Agglomerated Electrodes



M. Eikerling, A.A. Kornyshev, E. Lust  
*J. Electrochem. Soc.*, **152** (2005) E24




## Hierarchical model (Cantor-block model)



S.H. Liu, *Phys. Rev. Letters*, **55**(1985) 5289  
 T.Kaplan, L.J.Gray, and S.H.Liu, *Phys. Rev. B* **35** (1987) 5379




## Cylindrical homogeneous porous electrode model (H. Göhr)




H. Göhr in *Electrochemical Applications/97*, www.zahner.de




## Bode diagram of EIS at different cell voltages measured at PEFC (H<sub>2</sub>/O<sub>2</sub>) at 80°C,



## EIS at Polymer Fuel Cells (PEFC): Contributions to the cell impedance at different current densities



## Evaluation of the U-i characteristics from EIS



◆ measured curve:  $U_n = f(i_n)$

■ calculated curve:  $U_n = i_n R_n$  (without integration)

△ calculated curve using method II:  $U_n = a_n i_n^2 + b_n i_n + c_n$

x calculated curve using method I:  $U_n = a_n i_n + b_n$

$$R_n = \left. \frac{\partial U}{\partial I} \right|_n$$

Integration method I:

$$U_n = U_{n-1} - \frac{1}{2} \left( \left. \frac{\partial U}{\partial I} \right|_{n-1} + \left. \frac{\partial U}{\partial I} \right|_n \right) * (I_n - I_{n-1})$$

Integration method II:

$$U_n = a_n I_n^2 + b_n I_n + c_n \quad \text{with:}$$

$$a_n = \frac{R_{n+1} - R_n}{2(I_{n+1} - I_n)}$$


$$b_n = R_{n+1} - 2a_n I_{n+1}$$

$$c_n = U_{n-1} - a_n I_{n-1}^2 - b_n I_{n-1}$$



## EIS at Polymer Fuel Cells (PEFC):


Contributions to the overall U-i characteristic determined by EIS





## Evaluation of EIS with the porous electrode model

### Summary of current density dependency of pore resistance elements




## Improved Evaluation Techniques for Time Resolved Electrochemical Impedance Spectroscopy (TREIS)

- Real time drift compensation
- Time course interpolation
- Z-HIT compensation



## Improved evaluation technique: Time course interpolation




### Requirements


- Series measurement
- Time for each
- measured frequency AND for each spectrum




## Reforming of Methane



## Appearance of voltage oscillations during galvanostatic operation of PEFC with H<sub>2</sub>+ 100ppm CO



## Time resolved EIS - CO poisoning of Pt-anode




Time progression of **cell voltage** and overvoltage in galvanostatic mode of PEFC operation (217 mAcm<sup>-2</sup>) Pt-anode, H<sub>2</sub> + 100 ppm CO at 80°C

Nyquist plot of **EIS** measured at different times during poisoning of the Pt-anode with CO





## Measured and simulated time resolved EIS - CO poisoning



Nyquist plot of EIS during CO poisoning of the Pt-anode at 217 mAcm<sup>2</sup>, H<sub>2</sub>+100 ppm CO





## Time resolved EIS - CO poisoning



Bode plot of EIS during CO poisoning of the Pt-anode at 217 mAcm<sup>2</sup>, H<sub>2</sub>+100 ppm CO



## Simulated EIS with Relaxation Impedance: Theory



$$\tau = 1 \text{ s}; R_k = 10 \text{ m}\Omega; R_\eta = 100 \text{ m}\Omega$$

$$R_M = 5 \text{ m}\Omega; C_{dl} = 10 \text{ mF}$$

$$Z_F(\omega \rightarrow 0) = R_F = 9,1 \text{ m}\Omega$$

**Faraday-impedance:**  $Z_F = R_\eta / (1 + R_\eta / Z_k)$

**Relaxation imp.:**  $Z_k = (1 + i\omega\tau) / I_F d\ln k / dE$


Time constant:  $\tau = R_k L_k$

Relaxation resistance:  $R_k = 1 / I_F d\ln k / dE$

Relaxation inductivity:  $L_k = \tau R_k$







## Time resolved EIS Flooding the cathode at 2 A, dead end







## Time resolved EIS, flooding the cathode at 2 A, 80°C; time dependency of the cell voltage and impedance elements




## Change of cell voltage during constant load at 500 mA cm<sup>-2</sup>




## Bode Plot of EIS measured during PEFC operation over 1000 h at 500 mA cm<sup>-2</sup>




## Variation of RC during PEFC operation at 500 mA cm<sup>-2</sup>




## Variation of $R_A$ during PEFC operation at 500 mA $\text{cm}^{-2}$




## Evaluation and Analyse of Voltage Loss by EIS



## AFC: Impedance Measurements during ORR in 10 N NaOH, on Silver Electrodes at Different Current Densities, $i < -50 \text{ mAcm}^{-2}$




Bode representation




Nyquist representation



## Impedance Measurements during ORR in 10 N NaOH, on Silver Electrodes at Different Current Densities, $i > -50 \text{ mAcm}^{-2}$



Bode representation



Nyquist representation



## Adsorptions- and heterogeneous reaction impedance

Definition of  $Z_{ad/het}$  :

$$Z_{ad/het} = RT(k-i\omega)/n^2F^2c_sA(k^2+\omega^2)$$

With  $A$ =electrode surface,  $k$ = first order reactions rate,

$F$ =Faraday constant,  $c_s$ =surface concentration and angular frequency  $\omega=2\pi f$ .


The heterogenous reaction impedance can be converted into a parallel combination of  $R_{ad/het}$  and  $C_{ad/het}$  :

$$R_{ad/het} = RT/(n^2F^2c_sAk)$$

$$C_{ad/het} = n^2F^2c_sA/(RT)$$




## Electrode Model with cylindrical , homogeneous pores and complex Faraday-impedance






## Evaluation of EIS measured during ORR


### Equivalent circuit and $R_{ad} = f(i)$




## U-i characteristic and current density dependency of impedance elements $R_{ad}$ and $R_{ct}$




## Current density dependency of $k_{ad}$ , $R_{ad}$ and $R_{ct}$ , determined from EIS evaluation



## Impedance Spectroscopy at SOFC short stack




## Comparison of the sequential measurement principle for impedance spectra data acquisition with the synchronous parallel approach



<http://www.zahner.de/products/addon-cards/pad4.html>



## Nyquist impedance diagram of the five individual cells within the SOFC short stack at OCP (1.19 V), measured synchronously



Operation under dry fuel gas (50 %  $H_2$  + 50 %  $N_2$  and air at 750 C°. Symbols: measurement data, solid lines: model fit




## Conclusion

- **Determination of the individual potential losses during fuel cell operation**
- **Determination of degradation mechanism and performance loss**
- **Improvement of fuel cell performance and stability by understanding instead of trial and error**
- **Determination of critical operation conditions of fuel cells**



# Thank you for the attention!



Norbert Wagner, “Electrochemical power sources – Fuel cells”, in Impedance Spectroscopy: Theory, Experiment, and Applications, 2<sup>nd</sup> Edition, Edited by Evgenij Barsoukov and J. Ross Macdonald, John Wiley&Sons, Inc., 2005, pp. 497-537, ISBN: 0-471-64749-7

